



# BD Parata ATP™ 2

## Pouch Packager

Automating your adherence packaging program **helps to extend your reach** to patients and partners, can help provide an easy way for patients to manage their medications and streamline workflows for your pharmacy.



# Secure and customizable

BD Parata ATP™ 2 Pouch Packager automates your dispensing processes for oral solid medications while giving you the flexibility to customize pouches to fit any patient population.

## Highlighted Features

- Up to 51 pouches/minute and 65 pouches/minute for multi-dose and unit-dose pouches, respectively.\*
- Scalable with up to 320 canisters in one cabinet size. Two add-on units expand capacity to 400 and 480 canisters.
- Four pouch sizes for multi or single doses.
- Dual tray system allows for continuous operation.
- Flexible and intelligent software with biometric scanning, reporting, and drag-and-drop editing for customized pouch designs.

\* Tested at one-minute intervals, actual speeds may vary depending on quantity of units per pouch, pouch size (e.g., length), and additional non-medication pouches (e.g., header pouches).

## Included with your purchase of a BD Parata ATP™ 2 Pouch Packager

- Calibrated canisters based on the formulary (Dependent on machine size)
- Pre-Fill Tray for Non-canister Meds (1)
- Laser Printer (1) - Integrated Scale for Inventory Tracking (1)
- Cleaning and Startup Kit Including Common Tools, Paper and Ribbon (1)
- Dispense manager software suite and workstations which includes: 1 Client Control Station, 1 Workstation (Each station comes with biometrics), GS1 Barcode Capable Scanners

## Optional Complements

- Parata ATP™ Workstations
- BD Parata InspectRx™ & BD Parata PerI™ Pouch Inspector
- Universal Lighted Tray (ULT™) System
- Swappable Packager (Lower Packaging Unit)
- Canister Calibration Kit
- Parata ATP™ Standard Canisters
- Parata ATP™ Smart Canisters
- Parata ATP™ Adjustable Canisters & Calibration Tool
- Spoolers and Winders

Parameters	Specifications
Power Requirements	120V / 15A / 60Hz outlets (2 each)
Network Requirements	Ethernet RJ-485 (Cat VI)



# BD Parata ATP™ 2 Pouch Packager



Smart canisters can be placed in any Parata ATP™ 2 drawer and recognized by our technology.



Adjustable canisters help save time and costs for new meds and reduced tray fills.



Parata ATP™ 2's scalability keeps up with continued business growth.



Continuous improvement reporting for inventory management and usage.

Biometric scanning for user login.

Dual Tray allows for continuous production.

Customizable printing on pouches: various font sizes, styles, logos and icons, extended barcodes including 2D and linear.

Parameters	Width (in)	Height (in)	Depth (in)
≤320 Cabinet	42	87	31
400 Cabinet	52	87	31
480 Cabinet	63	87	31
		Transportation Weight (without canisters)*	Loaded Weight (with empty canisters)*
You'll also need counter space for the workstation.	Lower Packaging Unit	99	99
	≤320 Cabinet	1378 lbs	1573 lbs
	400 Cabinet	1719 lbs	1963 lbs
	480 Cabinet	2061 lbs	2354 lbs

\* weights listed are estimates

BD—Canada, Mississauga, ON, L5N 0B3

[bd.com](http://bd.com)



BD, the BD Logo, Parata ATP, Parata InspectRx, Parata Perl and ULT are trademarks of Becton, Dickinson and Company or its affiliates. © 2024 BD. All rights reserved. BD-115160 (0824)